


IMPORTANT:

Make sure your printer prints at actual size - many default to 'print to fit' which will shrink this image



Measuring the hoof:

Place a piece of card under the hoof and trace tightly around the edge of the hoof. Cut out the tracing and place over this chart to determine the size for the Jogging Shoe.

The hoof should be at its largest when you measure to make sure that the shoe fits the hoof throughout the whole trim cycle. If the hoof is freshly trimmed, add 0.5cm to the sizing. If the hoof is between sizes choose the larger size.

www.equinejoggingshoe.com

	Length	Width	SLIM width
Size 7	6.6-7.5cm (2 5/8-2 15/16")	up to 7.5cm (2 3/4")	up to 6.35cm (2 1/5")
Size 8	7.6-8.5cm (3-3 3/8")	up to 8cm (3 5/32")	up to 7.35cm (2 7/8")
Size 9	8.6-9.5cm (3 3/8-3 3/4")	up to 9cm (3 9/16")	up to 8.35cm (3 5/16")
Size 10	9.6-10.5cm (3 3/4-4 1/8")	up to 10cm (3 15/16")	up to 9.35cm (3 11/16")
Size 11	10.6-11.5cm (4 3/16-4 1/2")	up to 11cm (4 5/16")	up to 10.35cm (4 1/8")
Size 12	11.6-12.5cm (4 9/16-4 15/16")	up to 12cm (4 3/4")	up to 11.35cm (4 1/2")
Size 13	12.6-13.5cm (4 15/16-5 5/16")	up to 13cm (5 1/8")	up to 12.35cm (4 7/8")
Size 14	13.6-14.5cm (5 3/8-5 11/16")	up to 14cm (5 1/2")	up to 13.35cm (5 1/4")
Size 15	14.6-15.5cm (5 3/4-6 1/8")	up to 15cm (5 15/16")	up to 14.35cm (5 11/16")
Size 16	15.6-16.5cm (6 1/8-6 1/2")	up to 16cm (6 5/16")	up to 15.36cm (6 1/16")